



# RELAY SIGNAL OUTPUT



Wiring Schematic for RS-080, RS-090, RS-094  
RS-096, and RS-097 Dry Signal Contact  
Wiring to a Plug-In Relay

PROPRIETARY INFORMATION	UNLESS OTHERWISE SPECIFIED	INITIALS	DATES	FloodMaster LLC 27 Business Park Drive Branford, CT 06405	
		BB	1/20/2015		
THE INFORMATION CONTAINED IN THIS DOCUMENT IS THE PROPERTY OF FLOOD MASTER COMPANY. IT IS SUBJECT TO RETURN UPON DEMAND AND MAY NOT BE REPRODUCED OR OTHERWISE DISCLOSED WITHOUT WRITTEN PERMISSION FROM FLOOD MASTER COMPANY.	DIMENSIONS ARE IN INCHES			TITLE: FloodMaster Optional Control Wiring	
		SIZE: A	CAGE Code: None	DWG NO.: 063-M04787	
				SCALE: None	
				SHEET: 1	

# RELAY SIGNAL OUTPUT



Wiring Schematic for RS-080, RS-090, RS-094  
RS-096, and RS-097 Dry Signal Contact  
Wiring to a Relay

PROPRIETARY INFORMATION	UNLESS OTHERWISE SPECIFIED	INITIALS	DATES	FloodMaster LLC 27 Business Park Drive Branford, CT 06405		
		BB	1/20/2015			
THE INFORMATION CONTAINED IN THIS DOCUMENT IS THE PROPERTY OF FLOOD MASTER COMPANY. IT IS SUBJECT TO RETURN UPON DEMAND AND MAY NOT BE REPRODUCED OR OTHERWISE DISCLOSED WITHOUT WRITTEN PERMISSION FROM FLOOD MASTER COMPANY.	DIMENSIONS ARE IN INCHES			TITLE: FloodMaster Optional Control Wiring		
				SIZE: A	CAGE Code: None	DWG NO.: 063-M04788
				SCALE: None		SHEET: 1